



# Operators Manual

Doc #P10226 Rev 1.7

# Table of Contents

|                                                                   |        |
|-------------------------------------------------------------------|--------|
| Part Numbers                                                      | Pg. 4  |
| Overview                                                          | Pg. 4  |
| Features                                                          | Pg. 4  |
| General Specifications                                            | Pg. 5  |
| Radio Transceiver Specifications                                  | Pg. 5  |
| Mounting Orientation and Guidelines                               | Pg. 6  |
| Device Overview and Description                                   | Pg. 6  |
| Controller Interface – Top edge connector                         | Pg. 7  |
| Remote Interface – Top edge connector                             | Pg. 7  |
| Controller Interface – Bottom edge connector                      | Pg. 8  |
| Remote Interface – Bottom edge connector                          | Pg. 8  |
| Jumpers JP1 and Jp2 (Remote Interface only)                       | Pg. 9  |
| "Test" Push Button                                                | Pg. 10 |
| LEDS                                                              | Pg. 10 |
| Antenna                                                           | Pg. 10 |
| Providing Power to the Controller and Remote Interfaces           | Pg. 11 |
| Battery Backup Charging and UPS Functionality                     | Pg. 11 |
| Wiring Wiegand on Remote/Controller Interfaces                    | Pg. 12 |
| R1 Wired on Remote Interface/ R1 IN Wired on Controller Interface | Pg. 14 |
| R3 IN Wired on Remote Interface/ R3 Wired on Controller Interface | Pg. 16 |
| R4 IN Wired on Remote Interface/ R4 Wired on Controller Interface | Pg. 18 |
| POWER and BATTERY LED Diagnostics                                 | Pg. 19 |
| Mounting the Unit                                                 | Pg. 21 |

|                                               |        |
|-----------------------------------------------|--------|
| Troubleshooting                               | Pg. 23 |
| FCC and Industry Canada Regulatory Statements | Pg. 24 |
| Warranty                                      | Pg. 25 |

## Figure Reference Guide

|                                                                    |        |
|--------------------------------------------------------------------|--------|
| Figure 1: Interface Label Diagram                                  | Pg. 6  |
| Figure 2: JP1 / JP2                                                | Pg. 9  |
| Figure 3: Diagram of Power Input, +VBUS, and JP1/JP2 functionality | Pg. 9  |
| Figure 4: Backup Battery Connection                                | Pg. 11 |
| Figure 5: Wiegand Wiring Remote Interface                          | Pg. 12 |
| Figure 6: Wiegand Wiring Controller Interface                      | Pg. 13 |
| Figure 7: R1 Wiring Remote Interface                               | Pg. 14 |
| Figure 8: R1 IN Wiring Controller Interface                        | Pg. 15 |
| Figure 9: R3 IN Wiring Remote Interface                            | Pg. 16 |
| Figure 10: R3 Wiring Controller Interface                          | Pg. 17 |
| Figure 11: R4 IN Wiring Remote Interface                           | Pg. 18 |
| Figure 12: R 4 Wiring Controller Interface                         | Pg. 19 |
| Figure 13: DIN Rail Mounting Pins                                  | Pg. 21 |
| Figure 14: Top DIN Rail Screw Mount                                | Pg. 22 |
| Figure 15: Bottom DIN Rail Screw Mount                             | Pg. 22 |

## Part Numbers

|                  |                                                                   |
|------------------|-------------------------------------------------------------------|
| DS004-BRIDGE     | Wiegand Bridge system: includes DS004-CONTROLLER and DS004-REMOTE |
| DS004-CONTROLLER | Controller Interface                                              |
| DS004-REMOTE     | Remote Interface                                                  |

## Overview

The DS004 Wiegand Bridge System consists of two units: The Controller Interface, Model DS004-CONTROLLER, and the Remote Interface, Model DS004-REMOTE. The system provides a wireless connection (bridge) from a remote location, such as at a door, to the controller location at the access control panel. The Controller Interface connects with the access control panel and communicates wirelessly to the Remote Interface, which is placed near any peripheral Wiegand device (card reader / keypad / receiver /etc). Each DS004 Bridge System consists of one Wiegand input, two relay outputs and inputs for door monitor sensors/request to exit inputs. The Sure-Fi App provides troubleshooting, diagnostics information, and field upgrades.

## Features

- Includes complete wireless solution from Remote location (reader/door) to Controller location
- Range: up to 1 mile through obstructions and greater than 50 miles line-of-sight.
- One Wiegand input (compatible with any Wiegand protocol)
- Two relay outputs (NO, NC, COM terminals) Wet or Dry contacts.
- Request to exit input (REX)
- Door monitor input (DPS)
- Backup Battery charger and UPS function
- DIN rail mount or direct wall mount
- One Auxiliary input

## General Specifications

|                         |                                                                                                               |
|-------------------------|---------------------------------------------------------------------------------------------------------------|
| Operating Voltage:      | 12VDC +/- %5                                                                                                  |
| Operating Current:      | @ 12VDC: 0.08A (idle), 0.3A (transmit)                                                                        |
| Operating Power:        | 3.6 Watt (peak)                                                                                               |
| Battery backup:         | 12V sealed lead acid (SLA) type (not included)                                                                |
| Battery Low Threshold:  | < 11VDC                                                                                                       |
| Battery Charge Voltage: | 13.75V maximum at standby charge.                                                                             |
| Battery Charge Current: | 0.125A maximum at low battery voltage level.                                                                  |
| Relay Outputs:          | Two relays: 2A 250VAC / 250VDC. NO, NC, COM, Wet / Dry<br>Note: Maximum allowable combined current is 3 Amps. |
| Range:                  | Up to 1 mile through obstructions.<br>Greater than 50 miles line-of-sight                                     |
| Operating Temperature:  | -40°C to +85°C (-40°F to +185°F)                                                                              |
| Storage Temperature:    | -55°C to +125°C (-67°F to +257°F)                                                                             |
| Humidity:               | 0 to 95% non-condensing                                                                                       |
| Dimensions (L x W x H): | 90mm x 107mm x 32.5mm (3.54" x 4.23" x 1.28")                                                                 |
| DIN mount type:         | 35mm x 7.5mm DIN rail (DIN46277-3)                                                                            |
| Degree of Protection:   | IP20 to IEC/EN 60529                                                                                          |

## Radio Transceiver Specifications


|                       |                        |
|-----------------------|------------------------|
| Transmit Power:       | 1 Watt (30dBm)         |
| Frequency Band:       | 902 – 928MHz           |
| Channels:             | 72 (Frequency hopping) |
| Receiver Sensitivity: | -133dBm                |
| Link Budget:          | 163dB                  |

# Mounting Orientation and Guidelines

The Controller and Remote Interfaces are tested and certified to be oriented with the Antenna positioned at top side of the unit and mounted vertically as shown in Figure 1. For the best radio performance, route all wires and cables away from the Antenna.

## Device Overview and Description (Remote shown)

Figure 1: Interface Label Diagram



## Controller Interface - Top edge connector

| Position  | Description                                               |
|-----------|-----------------------------------------------------------|
| 1 (right) | R4 NC: Relay 4 Normally-Closed terminal                   |
| 2         | R4 COM: Relay 4 Common terminal                           |
| 3         | R4 NO: Relay 4 Normally-Open terminal                     |
| 4         | R2 IN: Relay 2 control (energizes Relay 2 on paired unit) |
| 5         | GND: - DC input                                           |
| 6         | R1 IN: Relay 1 control (energizes Relay 1 on paired unit) |
| 7         | GND: - DC input                                           |
| 8         | R3 NC: Relay 3 Normally-Closed terminal                   |
| 9         | R3 COM: Relay 3 Common terminal                           |
| 10 (left) | R3 NO: Relay 3 Normally-Open terminal                     |

## Remote Interface - Top edge connector

| Position  | Description                                               |
|-----------|-----------------------------------------------------------|
| 1 (right) | R2 NC: Relay 2 Normally-Closed terminal                   |
| 2         | R2 COM: Relay 2 Common terminal                           |
| 3         | R2 NO: Relay 2 Normally-Open terminal                     |
| 4         | R4 IN: Relay 4 control (energizes Relay 4 on paired unit) |
| 5         | GND: - DC input                                           |
| 6         | R3 IN: Relay 3 control (energizes Relay 3 on paired unit) |
| 7         | GND: - DC input                                           |
| 8         | R1 NC: Relay 1 Normally-Closed terminal                   |
| 9         | R1 COM: Relay 1 Common terminal                           |
| 10 (left) | R1 NO: Relay 1 Normally-Open terminal                     |

## Controller Interface - Bottom edge connector

| Position   | Description                                                                                                                         |
|------------|-------------------------------------------------------------------------------------------------------------------------------------|
| 1 (left)   | +12VDC: + DC input                                                                                                                  |
| 2          | GND: - DC input                                                                                                                     |
| 3          | BAT+: Battery backup positive terminal '+' connection. 12V Sealed Lead Acid (SLA) type battery only.                                |
| 4          | GND: - DC input                                                                                                                     |
| 5          | NC: Not Connected                                                                                                                   |
| 6          | GND: - DC input (Wiegand Ground connection)                                                                                         |
| 7          | D0: Wiegand D0 connection                                                                                                           |
| 8          | D1: Wiegand D1 connection                                                                                                           |
| 9          | LED: Device LED connection                                                                                                          |
| 10 (right) | AUX-OUT: This is an output on the CONTROLLER INTERFACE, and corresponds with the AUX-IN on the REMOTE INTERFACE, which is an input. |

## Remote Interface - Bottom edge connector

| Position   | Description                                                                                                                         |
|------------|-------------------------------------------------------------------------------------------------------------------------------------|
| 1 (left)   | +12VDC: + DC input                                                                                                                  |
| 2          | GND: - DC input                                                                                                                     |
| 3          | BAT+: Battery backup positive terminal '+' connection. 12V Sealed Lead Acid (SLA) type battery only.                                |
| 4          | GND: - DC input                                                                                                                     |
| 5          | VBUS: + voltage output for Wiegand device (See Figure 3)                                                                            |
| 6          | GND: - DC input (Wiegand Ground connection)                                                                                         |
| 7          | D0: Wiegand D0 connection                                                                                                           |
| 8          | D1: Wiegand D1 connection                                                                                                           |
| 9          | LED: Device LED connection                                                                                                          |
| 10 (right) | AUX-IN: This is an Input on the REMOTE INTERFACE, and corresponds with the AUX-OUT on the CONTROLLER INTERFACE, which is an output. |



## Jumpers JP1 and JP2 (REMOTE INTERFACE ONLY)

Jumpers JP1 / JP2 are used to connect the relay COM terminal to either GND or +VBUS. JP1 is for Relay 1, JP2 is for Relay 2. Figure 2 shows the pinout of JP1/JP2. Use the supplied Jumper to connect the common terminal to either the – GND or the + VBUS pins if required for the desired application. The + VBUS is the same voltage that is present on the power input at the +12VDC input, or if the Backup battery is in use, on BAT+. The Remote Interface is delivered with the supplied Jumpers on JP1 and JP2 set for a dry relay (COM not connected to either GND or +VBUS), see figure 3.

Figure 2: JP1 / JP2 Pinout





Figure 3: Diagram of Power Input, +VBUS, and JP1/JP2 functionality



## “Test” Push Button

The push button is used for two functions:

1. Range Test: Pressing and releasing the button quickly initiates the Range Test. The Range Test feature is used to test the range of the radio transceiver and displays the results of a received transmission on the LED's labeled 'Signal Strength' (1 – 6) in Figure 1.
2. Configuration: Pressing and holding the button down for 5 seconds will put the unit into Configuration mode. Before pressing the button, see the Sure-Fi App for configuration processes and other information.

## LEDS (Refer to Figure 1)

1. POWER and BATTERY LEDS: these two LED's provide power and battery input status information. See the 'LED Diagnostics' section for more information.
2. Rx LED: The Rx LED will flash once briefly when a Sure-Fi radio transmission is received.
3. Tx LED: The Tx LED will flash once briefly upon a radio transmission.
4. Signal Strength LED's: These six LED's display the received signal strength. Maximum signal strength is indicated when LED's 1 through 6 are all ON. Minimum signal strength is indicated when only LED 1 is ON.


## Antenna

The radio antenna is created using copper traces on both sides of the PC Board. Use caution when handling and mounting the unit to ensure that no damage (scratches, etc) occurs to the PC Board/Antenna. Additionally, for best performance, keep cables and wiring away from the antenna and mount the unit oriented with the antenna upwards.

## Providing Power to the Controller & Remote Interfaces

The Controller and Remote interfaces each require a 12VDC supply that can source 1.0 Amp. If a maglock, strike, or other device is to be powered through the wet relay, then the additional power required for those devices will need to be considered when selecting a power supply. A Battery backup can be connected as shown if required for the application.

Figure 4: Backup Battery Connection




## Battery Backup Charging and UPS Functionality

The Controller and Remote Interfaces both provide a charging voltage for a 12V sealed lead acid battery backup and they also have uninterruptable power supply (UPS) functionality. The UPS will automatically switch to the battery backup whenever the 12VIN wall power goes out and will then switch back to the 12VIN wall power when it returns.

# Wiring Wiegand On Remote/Controller Interfaces

Figure 5: Wiegand Wiring Remote Interface

**WARNING - Wiegand Device must be 12VDC Compatible**



Wiegand terminals on the Remote Interface correspond directly with the Wiegand terminals on the Controller Interface.

Dual LED Wiring: Some devices have single wire, two LED modes. Connect a 470 Ohm resistor to R1 NC Relay contact and connect JP1 jumper to COM and +(VBUS) which connects R1 COM to +12VDC. If other voltage or LED brightness is required, scale resistor value accordingly.





Figure 6: Wiegand Wiring Controller Interface




Wiegand terminals on the Controller Interface are wired to the control panel with **D0, D1, and GND** wires only.

Note: + power and LED do not need to be wired on the Controller side.

# Relay 1 Wired On Remote Interface / Relay 1 In Wired On Controller Interface


Figure 7: Relay 1 Wiring Remote Interface



**WARNING: THE PROVIDED SURGE PROTECTOR MUST BE INSTALLED AS SHOWN AS CLOSE TO THE BRIDGE CONNECTOR AS POSSIBLE – EVEN IF THERE IS A SURGE PROTECTOR ALREADY ON THE STRIKE/LATCH.**

**FAILURE TO COMPLY MAY RESULT IN ERRATIC BRIDGE BEHAVIOUR OR PERMANENT DAMAGE.**

Figure 8: R1 IN Wiring Controller Interface



**R1 IN**

**Relay 1 (R1 IN)** input on the Controller Interface corresponds directly with Relay 1 NO/NC terminals on the Remote Interface.

# Relay 3 In Wired On Remote Interface / Relay 3 Wired On Controller Interface

Figure 9: R3 IN Wiring Remote Interface








Figure 10: Relay 3 Wiring Controller Interface



# Relay 4 In Wired On Remote Interface / Relay 4 Wired On Controller Interface


Figure 11: R4 IN Wiring Remote Interface



### R4 IN / GND

**R4 IN** input on the Remote Interface corresponds directly with **Relay 4** on the Controller Interface. This input can be used for a door monitor/door position sensor, request to exit or other device needing a relay output. Use terminal **R4 IN** and **GND** to wire the device on the Remote Interface.

Figure 12: Relay 4 Wiring Controller Interface



## Power and Battery Led Diagnostics

The two green LED's that are labeled 'POWER' and 'BATTERY' (See Figure 1) are used to provide the status of the 12VDC input ('POWER' LED) and Battery input voltage ('BATTERY' LED). The status information is described here:

### Power Status: POWER LED

| LED STATE        | DESCRIPTION                                                |
|------------------|------------------------------------------------------------|
| ON               | Normal input voltage                                       |
| Slow Flash (1Hz) | Input voltage low. Check for proper input voltage (12VDC)  |
| Fast Flash (2Hz) | Input voltage high. Check for proper input voltage (12VDC) |
| OFF              | No input power or device not functioning properly          |

### Battery Status: BATTERY LED

| LED STATE        | DESCRIPTION                                              |
|------------------|----------------------------------------------------------|
| ON               | Battery voltage normal                                   |
| Slow Flash (1Hz) | Low battery voltage. Battery voltage is < 11.0VDC        |
| Fast Flash (2Hz) | Battery voltage high. Maximum Battery voltage is 13.8VDC |
| OFF              | No battery: battery voltage is < 1.0VDC                  |

## Mounting The Unit

There are two methods for mounting:

### DIN Rail mount:

DIN rail mounting is the preferred mounting method that allows the case to easily clip and unclip from the DIN rail. Attach a piece (minimum 4" length) of 35mm type DIN rail to the wall and then snap the unit to the DIN rail or slide it on from the end. The unit will snap in to place by putting the top retaining tabs on to the DIN rail first, then pressing the bottom on to the DIN rail until it snaps in to place. To remove the unit from the DIN rail, use a small screwdriver, insert in to the bottom DIN rail clip (the single black clip) and pull gently down and outward until the unit releases from the DIN rail.

### Screw mount:

The DIN rail clips on the base of the enclosure case can be snapped outward to allow for screw mounting of the case. Mount using only the single bottom black DIN clip and the top white DIN clip that is located on the side below connector P1. Do not use the DIN clip located behind the antennae.


The two DIN clips are shown pressed outward and ready for screw mounting:

Figure 13: DIN Rail Mounting Pins



The top screw is shown mounted through the DIN clip to the wall:

Figure 14: Top DIN Rail Screw Mount



The bottom screw is shown mounted through the black DIN clip to the wall:

Figure 15: Bottom DIN Rail Screw Mount



## Troubleshooting

If the Controller and Remote Interfaces are not communicating:

First try quickly pressing and releasing the 'Test' button on one of the units and observing the six Signal Strength LED's. If any of blue LED 1 through LED 6 LED's light up then the transmission between the two units was successful.

Another test can be attempted by presenting a credential to the Wiegand device –

Observe the Rx and Tx LEDs on either the Controller or the Remote Interface and ensure the following happens:

1. The Transmit (Tx) LED flashes.

And immediately after

2. The Receive (Rx) LED flashes.

If you do not see the transmit and receive LED lights activate:

1. Power cycle both the Controller and Remote Interfaces, then retest.
2. Ensure that any wires and cables are routed away from the Antenna on both Controller and Remote Interfaces.
3. Ensure that Surge Protector(s) are properly installed.

For maximum range between the Controller and Remote Interfaces:

1. Power both units with their own dedicated power supply.
2. Place both units at higher locations.
3. Route all cables and wiring away from the area around the Antenna.

If successful communication occurs using the 'Test' button, but does not occur using the Wiegand device, then the problem is likely incorrect wiring to the Wiegand device or an incompatibility issue with the Wiegand device.

## FCC and Industry Canada Regulatory Statements

### FCC

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by manufacturer could void the user's authority to operate the equipment.

IMPORTANT! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

### Industry Canada

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IMPORTANT! Tous les changements ou modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner cet équipement.

### 47 CFR 15.105- FCC

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada



#### FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

#### Important Note:

##### Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

#### Note Importante: (Pour l'utilisation de dispositifs mobiles)

##### Declaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

## Warranty

The warranty period of this product is 12 months run-time, beginning from first power up of the device after purchase. During this period, if the product does not operate correctly, due to a defective component, the product will be repaired or replaced at the sole discretion of Sure-Fi, Inc. This warranty does not extend to the product casing which can be damaged by conditions outside of the control of Sure-Fi, Inc.

EXCEPT AS SET FORTH ABOVE, SURE-FI, INC. MAKES NO WARRANTIES REGARDING THE GOODS, EXPRESS OR IMPLIED, INCLUDING WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. BUYER MAKES NO RELIANCE ON ANY REPRESENTATION OF SURE-FI, INC., EXPRESS OR IMPLIED, WITH REGARD TO THE GOODS AND ACCEPTS THEM "AS-IS/WHERE-IS". SURE-FI, INC SELLS THE GOODS TO BUYER ON CONDITION THAT SURE-FI, INC. WILL HAVE NO LIABILITY OF ANY KIND AS A RESULT OF THE SALE. BUYER AGREES THAT SURE-FI, INC. SHALL HAVE NO LIABILITY FOR DAMAGES OF ANY KIND, WHETHER DIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING INJURIES TO PERSONS OR PROPERTY, TO BUYER, ITS EMPLOYEES OR AGENTS, AS A RESULT OF THE SALE. BUYER ALSO AGREES TO HOLD SURE-FI, INC. HARMLESS FROM ANY CLAIMS BUYER, OR ANY THIRD PARTY, MAY HAVE AS A RESULT OF BUYER'S USE OR DISPOSAL OF THE GOODS. BUYER HAS READ THIS DISCLAIMER AND AGREES WITH ITS TERMS IN CONSIDERATION OF RECEIVING THE GOODS.

#### Trademarks

Sure-Fi and the Sure-Fi logo are registered trademarks.

#### Copyrights

©2017 Sure-Fi, Inc. All rights reserved.